



- 1- DanPal panel
- 2- AirPT Frame closure
- 3- AirPT gasket
- 4- AirPT water removal
- 5- AirPT frame base
- 6- AirPT foam
- 7- AirPT spacer
- 8- free expansion U connector